



# Gain

Audio Signal Modification Unit  
User Manual And Technical Reference

ACOUSTIC RESEARCH





In this our 20th year of operation, and on behalf of the entire company; I would personally like to express my deepest gratitude for your continued support of our products and services.

Here at Acoustic Research, we pride ourselves in the quality of our instruments and ensure that every one meets the high standards that our customers deserve. I have no doubt, that the equipment that you have received today will meet those standards just as they did 20 years ago.

I wish you the greatest success in your research

*James Chaffinch*  
James Chaffinch, CEO

References in this publication to Acoustic Research products, programs, or services do not imply that Acoustic Research intends to make these available in all countries in which Acoustic Research operates. Any reference to an Acoustic Research product, program or service is not intended to state or imply that only Acoustic Research's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of Acoustic Research's intellectual property rights or other legally protectable rights may be used instead of the Acoustic Research product, program, or service. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by Acoustic Research, are the user's responsibility.

Acoustic Research may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to an Acoustic Research authorized dealer or your Acoustic Research marketing representative, who will be able to forward on the request.

The following terms in this publication are trademarks of Acoustic Research Inc. In the European Union and/or other countries / economic areas.

- Acoustic Research

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Acoustic Research may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time.

It is possible that this publication may contain reference to, or information about, Acoustic Research products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Acoustic Research intends to announce such Acoustic Research products, programming, or services in your country.

Requests for technical information about Acoustic Research products or services for those products, whether they be repair, maintenance or upgrade; should be made to your Acoustic Research authorized dealer or your Acoustic Research marketing representative.

This product's connections follow the Coordinated Universal Interworking Standard (CUIIS) and as such can be used with any other product from any manufacturer that also adheres to this standard.

# Contents

Description	1
Interface	3
Unit Specifications	5

# Description

The Gain unit is an audio signal modification device which implements a simple equation used to affect the amplitude of an audio signal.

The equation is defined as such;

$$\text{output} = \text{input} \times \left( \text{multiplier} \times \left( \text{gain value} + \text{offset} \right) \right)$$

The three values of these equations correspond to the three value sources on the device. See the 'Interface' section for details.


The selection dial allows for a gain value range from -1 to +1. The 'offset' value essentially changes that to a range of 0 to 2. The 'multiplier' value allows for the expansion of this range to -10 to +10 or 0 to 20.



# Interface

1. Control Select  
Used to select between using the dial/voltage input pair (4 and 9), or Audio Signal Control input (6)
2. Value Multiplier  
Used in conjunction with the selected value. This switch can be used to decide if the selected gain should be multiplied by a factor of 10 or not.
3. Value Offset  
Used in conjunction with the selected value. This switch can be used to decide if the selected gain should have 1 added to it or not.
4. Gain Value Dial  
Used for selecting the gain value
5. Audio Signal Output  
The audio signal output connection  
  
CUIS type: Orange
6. Audio Signal Gain Value Control  
An audio control input connection port used to control the Gain Value. Control is between the values of -1 and 1.  
  
CUIS type: Orange
7. Value Multiplier Toggle  
A signal control input connection port which directly modifies the Value Multiplier Switch (2). Active signals toggle this value.  
  
CUIS type: Red
8. Value Offset Toggle  
A signal control input connection port which directly modifies the Value Offset Switch (3). Active signals toggle this value.  
  
CUIS type: Red
9. Voltage Gain Value Control  
A voltage control input connection port which directly modifies the Gain Value Dial (4). Control is between the values of -1 and 1.  
  
CUIS type: Green
10. Audio Signal Input  
The audio signal input connection  
  
CUIS type: Orange





# Unit Specifications

